

Manual for **BRINKMANN** turntable LaGRANGE

design + service

Brinkmann Audio
Im Himmelreich 13
88147 Achberg
Tel.:08380/981195
Fax:08380/981233

www.brinkmann-audio.com
info@brinkmann-audio.com

Legal regulation of the European Community :

This turntable had been designed and tested according to the guidelines EN55013 and EN55020, and it meets the safety requirements EN60065.

Informations for Safety :

The turntable LaGRANGE is only to be used in dry rooms with an average temperature and is only allowed for 220-240V, 50...60Hz alternating current, or as otherwise stated on the back of power supply casing.

The power supply is only to be connected to grounded wall sockets.

Please connect or disconnect only when the mains plug is not connected to the mains. Always disconnect the power supply from the mains when the turntable is not used for a longer period of time (during holidays etc.) ! Never leave the power supply unattended while it is connected to the mains !

Always keep the turntable away from wet, heat and open fire ! Never expose it to the blazing sun ! Never place receptacles with fluids on the turntable or power supply !

Power supply:

Never open the casing while the power supply is connected to the mains !

Attention, dangerous voltage !

The power supply is equipped with a temperature limiter that switches off at about 65°C ; to guarantee a flawless function please make sure to have a free space for air circulation measuring 30cm above the power supply and 10cm on each side. The heatsinks are never to be covered !

After disconnecting from the mains, the turntable can be cleaned with a dry cloth (microfiber) or a brush, do not use wet cleaning, wet cleaning can cause damages !

Repairs, modifications etc. are only to be carried out by the company **BRINKMANN** itself or by specially authorized workshops !

The glass cover of the platter should be cleaned with multipurpose screen and surface wipes and a dry cotton cloth.

Never use solvent or sprays!



Technical details :

The turntable LaGRANGE is available in two different designs : one design features one tonearm base and the other design includes a second tonearm base, while motor and power supply are exactly the same.

The turntable consists of three independent parts : the plinth with the bearing and the tonearm base(s) drilled according to the customers tonearms needs, the motor and the power supply. The motor drives the platter via a round belt of rubber.

In the following, the three parts are specified as turntable, motor and power supply.

TURNTABLE :

The turntable features plinth, platter and bearing as well as the tonearm base.



The bearing heater is integrated in the plinth and ensures the constant temperature of the platter bearing (bearing clearance). A two pole socket takes the plug of the power supply. The electronical part is installed on a printed circuit board, completely enclosed in the metal mass of the plinth.

MOTOR :

The motor of the turntable is a separate part, independent from plinth and platter. The motor is connected via a three core line wire and a three pole plug with the matching socket at the power supply. A cap screw connects plug and socket, so an unintended removal of the plug is not possible.

POWER SUPPLY :

The casing of the power supply consists of metal, it is completely closed.

The power supply has an output line wire with a two pole plug matching for the connector of the plinth, located at the rear side. A cap screw ensures that an unintended removal of the plug is not possible.

The power supply features also the three pole socket for the connection with the motor and the a plug for the mains power cord.

Set up procedure for LaGRANGE turntable :

we recommend to use a ground base made from black granite stone (nero assoluto) of at least 60 cm by 42 cm (centimeters), or 23.6 by 16.5 inch.

First, the plinth complete with tonearm base is placed on top of the ground subplane, the bearing for the platter should be in the center of the plane, with the tonearm base right hand. The spikes are adjusted just to get in contact with the ground base surface (screwdriver No. 3), attention : the plinth should not lift from the ground.

The screw that fixes the tonearm base is unscrewed a little and the base is turned clockwise (or ccw) until the effective length of the tonearm is correct. Turn the plinth in that way, that the tonearm aligns with the right edge of the ground plane when rested in its armrest.

Next the plug for the heater of the bearing is connected at the back of the plinth, but not yet switched on. Bearing and platter must have the same temperature when the platter is layed on.

Therefore you hold the platter above the bearing, look through the center hole of the platter and look for the axle of the turntable. Then lay down the platter carefully, only the last two millimeters the platter will be exactly centered by the subplatter of the bearing. Here the platter must be lowered exactly vertical to place it without getting stuck.

Possibly the ground plate will get out of horizontal balance by the weight of the platter, please check the balance on the platter surface again.

The motor is placed opposite the tonearmbase on the left hand side, the distance to the platter should be about 1cm. Then the belt is tied around platter and motor pinion, the motor is moved back or forward to have the switch buttons freely accessible.

The motor is connected to the transistorized psu, or, if you have the tubed psu, directly to it's 3-pole socket. The transistor supply remains for the heater circuit of the bearing.

The speed adjustment is located behind the motor, 33 is left from front view and 45 is right. For this adjustment please lay a stroboscope plate on the platter and adjust with the help of the small screwdriver. We recommend to do this adjustment after at least 3 hours, when the turntable is warmed up. During these 3 hours please let the motor run to break in the belt and the bearings.

After connecting the preamp with the ground cable (close to output sockets) and interconnects you can start playing records.

For this the small center plastic ring is pushed over the axle, place the record on the platter, hold it with one hand at the outer rim to prevent it to move on the glass surface, and screw the record clamp on the axle until the record is flat on the surface of the platter. Don't screw down completely as the record will come up at the outer rim again.

The surface of the platter and record should be cleaned carefully as any dirt could cause clicks and pops on the record (please read the part Informations for safety). Never use solvent !

We strongly recommend to use a record cleaning machine for best results.

The LaGRANGE turntable will be delivered with following components :

Chassis (plinth)	+ screwdriver No. 6 for tonearmbase,
	+ screwdriver No. 3 for adjustable spikes,
Tonearmbase	+ cable for ground connection, + screws for tonearm,
Motor	+ screwdriver for speed adjustment,
Record platter	+ drive belt,
Record clamp	+ small center plastic ring for lifting the record center,
Transistor psu	+ power cord, for motor and for heater of bearing,

Datasheet

BRINKMANN

Im Himmelreich 13

88147 Achberg

Germany

tel: +49 8380 981195

fax: +49 8380 981233

mail: info@brinkmann-audio.com